

# Standard Use

◆ "Washlet" is a registered trademark of TOTO.

## WASH

Washing the rear.

For washing rear using mild water pressure.


Serves as a bidet for ladies.

## DRY

Dries wet parts using warm air.

## STOP

Stops rear washing and other operating functions.



● The function that can be used when you press the "REAR", "SOFT" or "BIDET" button during use.

### ■ PRESSURE

You can adjust the water pressure to one of five levels. ("-" : Softer, "+" : Stronger)  
 ※ When you press the button to flush, the position returns to the standard position (3rd position).

### ■ POSITION

You can adjust the position to one of five positions. (◀ to the front, ▶ to the rear)  
 ※ When you press the button to flush, the position returns to the standard position (3rd position).

### ■ OSCILLATE

The wand moves back and forth to wash your rear thoroughly.  
 ※ The setting changes between "ON" and "OFF" each time the button is pressed.

### ■ PULSATE

Washes with the water pressure pulsating between soft and strong.  
 ※ The setting changes between "ON" and "OFF" each time the button is pressed.

Low battery warning lamp



## FLUSH

FLUSH

LIGHT FLUSH


## OPEN / CLOSE

Toilet lid opens and the toilet seat closes.

Opens the toilet seat and toilet lid.



Remote control back side



### Display screen

※ Adjust settings, check status, etc.  
 The display goes out when no button on the remote control is pressed for 1 minute or more.

### Temperature

· Used for temperature adjustment.

### Menu / Return

· Used for setting.  
 · Used for going back to the previous screen.

### If the remote controller battery runs out

Use the operation panel on the unit.



### How to flush the toilet bowl in case of a power failure

Detach the panel on the right side as viewed from the front and flush the toilet bowl by operating the flush handle.



Toilet bowl flush handle

① Turn and hold it facing the back for longer than 2 seconds.


② After flushing, turn the handle toward you.




# How to Use


Easy setting by simple operation!

List of menus that can be set by remote control.

The setting menus and their number differ according to the model.



Select menus with , set items with , and enter settings with .



※1※2

① Make a selection while scrolling the menus with .

② You can set as desired

