


Press a button on the Washlet control panel; a beep sounds when the main unit receives the signal.



More comfortable! More Energy saver!

How to Use



Temperature Adjustment

Temperature can be changed to "Warm Water" and "Toilet Seat"

Displaying the temperature level of the pressed button

温度設定

便座 Toilet seat temperature button

温水 Warm water temperature button


高

低

1 便座 温水

Choose and press the button of the temperature that you want to set.

2 Press the button selected in step 1 repeatedly until a desired temperature level illuminates.



Energy saver features

Auto energy saver

The product detects time periods with infrequent use and lowers the toilet seat temperature automatically.

- It takes about 10 days for the product to determine the periods when it is used relatively less frequently.

You can turn the feature ON/OFF at your discretion.

Press the おまかせ

おまかせ ON To turn the Auto energy saver "ON"

おまかせ OFF To turn "OFF" LED goes out.

Timer energy saver

Once the time is set, the toilet seat heater turn off automatically during the set time period every day.
(The energy-saving time period can be set to 6 or 9 hours.)

Example When using energy-saving function for 6 hours (1 am - 7 am).

When the time (1 am) you want to start energy saving function is reached, press the タイマー button repeatedly until the "6" LED lights up.



Setting completed

